



Instruction Manual

Unique DV-ST UltraPure - Pneumatic: for valve sizes DN8-DN50 (1/4" to 2")



ESE01751-EN5 2014-02

Original manual

The information herein is correct at the time of issue but may be subject to change without prior notice

1. General information	4
1.1. General information	4
1.2. Valve design	5
2. Safety	6
2.1. Important information	6
2.2. Warning signs	6
2.3. Safety precautions	7
3. Installation	8
3.1. Unpacking/delivery	8
3.2. General installation	8
3.3. Installation angle on self-draining position	9
3.4. Drainability	9
3.5. Welding	9
3.6. Mounting of the bonnet	9
3.7. Recycling information	10
4. Operation	11
4.1. Operation	11
5. Maintenance	12
5.1. Replacing the diaphragms and seals	12
5.2. Replacing the diaphragm	12
5.3. Fasteners for assembly - Full composite actuator	14
5.4. Fasteners for assembly - Actuator with intermediate part in stainless steel	15
5.5. Replacement of actuator seals	15
6. Technical data	17
6.1. Control diagram / modes	17
6.2. Maximum working pressures	18
6.3. Size	21
6.4. Maximum working temperatures	21
6.5. Control pressure (guidelines)	22
6.6. Control pressure diagram	22

1 General information

1.1 General information

The compact diaphragm valve is low maintenance, has a pneumatic actuator and is available in the normally closed, normally open and air/air modes of operation.

The pneumatic actuator is available as a complete composite, composite with stainless steel intermediate part and in a complete stainless steel version - the latter two with ATEX approval. The actuator is dimensionally reduced to a minimum and is especially suited to applications where space is limited.

A wide range of accessories such as an electrical feedback unit, positioner, BUS systems or stroke limiter, allow optimal adaption to all types of control tasks.

Your attention is drawn to the fact that the valve includes a diaphragm which can possibly load electrostatically because of the flowing medium. Selection of the diaphragm with regard to the medium and temperature is the responsibility of the customer.

As the valve does not generate any heat according to EN 13463- 1 para 14.2 g, it is not necessary to display a temperature class sign with regard to surface temperature.

The defined maximum surface temperature depends on the operating conditions, which is the responsibility of the customers. If the valve is used outside the range of the ambient temperature and/or the process pressure, this manual is to be used as a guideline.

We highly recommend additional test(s) for any known special operating conditions. The customer is responsible for carrying out these tests.

This valve is not to be used in areas when aromatic hydrocarbons, such as Benzene, Toluene, Xylene or higher Alkylbenzene are present or are the main part of organic steams because the nameplate will not withstand these mediums. Should the valve be installed in such areas, the nameplate must be changed.

The hazards caused by chemical reactions between parts of the valve and the chemical mediums used have to be clarified between the manufacturer and customer.

For operating conditions and installation EN 60079-14 must be taken into consideration.

The valve has to be integrated into the potential equalisation system.

These valves are intended to close the medium (on/off or control) after installation into a pipeline. These valves can be used in potentially explosive areas (Area 1). These valves are not to be used for other applications other than those mentioned.

1.2 Valve design

Fig. 3.1




Fig. 3.2





Fig. 3.3



- 1 Indicator cap
- 2 Optical position indicator
- 3.1 Composite housing fig. 3.1
- 3.2 Composite housing fig. 3.2
- 3.3 Stainless steel housing fig. 3.3
- 4 Pre-loaded spring sets (NC)
- 5 Connection control air
- 6 Stroke spindle assembly in stainless steel
- 7.1 Piston PA-GF fig. 3.1
- 7.2 Piston PA-GF fig. 3.2
- 7.3 Piston SS fig. 3.3
- 8 Diaphragm
- 9 Fasteners
- 10.1 Intermediate part PPS fig. 3.1
- 10.2 Intermediate part in stainless steel fig. 3.2
- 10.3 Intermediate part in stainless steel fig. 3.3
- 11 O-Ring seals
- 12 Compressor incl. diaphragm holder
- 13 Nuts + washers
- 14 Stainless steel body (forged or cast)

2 Safety

*Unsafe practices and other important information are indicated in this manual.
Warnings are emphasised by means of special signs.*

2.1 Important information

Always read this manual before using the valve!

WARNING

Indicates that special procedures must be followed to avoid serious personal injury.

CAUTION

Indicates that special procedures must be followed to avoid damage to the valve.

NOTE

Indicates important information to simplify or clarify procedures.

2.2 Warning signs

General warning:



Caustic agents:



All warnings in the manual are summarised on this page.

Pay special attention to the instructions below so that serious personal injury and/or damage to the valve are avoided.

2.3 Safety precautions

Installation:

Always read the technical data thoroughly (See chapter 6 Technical data)

Always release compressed air after use

Never touch the moving parts if the actuator is supplied with compressed air

Never touch the valve or the pipelines when processing hot liquids or when sterilising

Never dismantle the valve with valve and pipelines under pressure

Never dismantle the valve when it is hot



Operation:

Never dismantle the valve with valve and pipelines under pressure

Never dismantle the valve when it is hot

Always read the technical data thoroughly (See chapter 6 Technical data)

Always release compressed air after use

Never touch the valve or the pipelines when processing hot liquids or when sterilising

Never touch the moving parts if the actuator is supplied with compressed air

Always rinse well with clean water after the cleaning

Always handle lye and acid with great care



Maintenance:

Always read the technical data thoroughly (See chapter 6 Technical data)

Always release compressed air after use

Never service the valve when it is hot

Never service the valve with valve and pipelines under pressure

Never put your fingers through the valve ports if the actuator is supplied with compressed air

Never touch moving parts if the actuator is supplied with compressed air



Transportation:

Always secure that compressed air is released

Always check that all connections are disconnected before attempting to remove the valve from the installation

Always drain liquid from valves before transportation

Always ensure that the valve is adequately secured during transportation - if specially designed packaging material is available, it must be used

3 Installation

The instruction manual is part of the delivery. Study the instructions carefully.

The items refer to the parts list and service kits section.

The valve is supplied as separate parts as standard (for welding).

The valve is assembled before delivery, if it is supplied with fittings.

3.1 Unpacking/delivery

Step 1

CAUTION

Alfa Laval cannot be held responsible for incorrect unpacking.

Check the delivery for:

1. Complete valve.
 2. Delivery note.
-

Step 2

1. Remove any packing materials from the valve/valve parts.
 2. Inspect the valve/valve parts for visible transportation damage.
 3. Avoid damaging the valve/valve parts.
-

3.2 General installation

Step 1



Always read the technical data thoroughly.


CAUTION

Alfa Laval cannot be held responsible for incorrect installation.

Avoid stressing the valve.

Pay special attention to:

- Vibrations.
- Thermal expansion of the pipelines.
- Excessive welding.
- Overloading of the pipelines.




Risk of damage!

- For draining the diaphragm valve and pipeline, the appropriate installation position has to be provided.
- Variable installation position for self-draining, see data on the installation angle.
- For diaphragm valves with weld ends, remove the actuator and diaphragm from the valve body before welding
- For applications in ex-proof areas, you must only wipe the composite actuator with a moist cloth.

The valves fulfil the conditions of the ATEX regulations 94/9 EG and can be installed in explosion-proof areas group II category 2.

Study the instructions carefully and pay special attention to the warnings!
The valve has welding ends as standard but can also be supplied with fittings.

3.3 Installation angle on self-draining position



Port size		ASME	ISO 2037	Series A/ DIN11866	Series B/ ISO 1127	BS 4825
DN	Inch	BPE				
8	1/4"	37°	27°	27°	22°	37°
15	1/2"	32°	23°	23°	18°	33°
20	3/4"	26°	23°	23°	15°	27°
25	1"	22°	25°	21°	20°	25°
40	1 1/2"	24°	24°	22°	18°	24°
50	2"	24°	24°	23°	20°	24°

3.4 Drainability

Proper drainability in horizontally installed pipes requires mounting of valve at the correct angle. See above table

To ensure proper drainability, the valve must be mounted at the correct angle. Proper installation is the responsibility of the system installer and/or user.

3.5 Welding

Step 1

All welding should be done by qualified personnel.

Disassemble the actuator from the valve body. See Replacing the Diaphragm for details.

Step 2

Perform the welding procedure on the body according to standard industrial practices.

Step 3

Reassemble the actuator to the valve body.

Step 4

Test the valve for correct operation before installing.

3.6 Mounting of the bonnet

For T-Valves, Tandem valves, Tank outlet valves and Block valves please note that the bonnet is mounted using studs and nuts instead of bolts and nuts.

3 Installation

*Study the instructions carefully and pay special attention to the warnings!
The valve has welding ends as standard but can also be supplied with fittings.*

3.7 Recycling information

- **Unpacking**

- Packing material consists of wood, plastics, cardboard boxes and in some cases metal straps
- Wood and cardboard boxes can be re-used, recycled or used for energy recovery
- Plastics should be recycled or burnt at a licensed waste incineration plant
- Metal straps should be sent for material recycling

- **Maintenance**

- During maintenance, oil and wear parts in the machine are replaced
- All metal parts should be sent for material recycling
- Worn out or defective electronic parts should be sent to a licensed handler for material recycling
- Oil and all non-metal wear parts must be disposed of in accordance with local regulations

- **Scrapping**

- At end of use, the equipment must be recycled according to relevant, local regulations. Besides the equipment, any hazardous residues from the process liquid must be taken into consideration and dealt with in a proper manner. When in doubt, or in the absence of local regulations, please contact your local Alfa Laval sales company
-

*Study the instructions carefully and pay special attention to the warnings!
Ensure that the valve operates smoothly.
The items refer to the parts list and service kits section.*

4.1 Operation



Always read the technical data thoroughly.
See chapter 6 Technical data



Always release compressed air after use.

CAUTION

Alfa Laval cannot be held responsible for incorrect operation.

Fig. 1 - Function NC: Normally Closed

In the de-energised status, the valve is closed by spring force. When the control medium is admitted to the actuator (connection below), the valve opens; when the control medium escapes, the valve is closed via spring force.

Fig. 2 - Function NO: Normally open

In the de-energised status, the valve is opened by spring force. When the control medium is admitted to the actuator (connection above), the valve closes; when the control medium escapes, the valve is opened via spring force.

Fig. 3 - Function AA: Air/Air (double acting)

The valve has no defined basic position. The valve is opened and closed by applying control pressure to the corresponding control connection. Connection below: open, connection above: close.

Fig. 1




Fig. 2





Fig. 3



5 Maintenance

*Study the instructions carefully and pay special attention to the warnings!
Ensure that the valve operates smoothly.
The items refer to the parts list and service kits section.*

5.1 Replacing the diaphragms and seals

Generally, the only routine maintenance required is the replacement of the diaphragm. The diaphragm replacement routine, depending on the medium, pressure, temperature and cycle (duration and temperature) of steam sterilisation between process runs, determines the optimum change cycle of the diaphragm.

As with all diaphragm valves, the diaphragm itself is the strongest component used. In addition to mechanical stress, the diaphragm is subject to wear resulting from the flow media. We recommend that the diaphragm is inspected after a maximum of 100,000 cycles.

If the flow medium is muddy or contains abrasive particles, we recommend more frequent inspections. The diaphragm can be checked by dismantling the valve body (see Section 5.2 Replacing the diaphragm)

For installation in ex-proof areas, we recommend that the springs are changed every 250,000 cycles.

5.2 Replacing the diaphragm

Before servicing any installed valve, you must:

- depressurise the system
- open the valve
- purge the valve

Note: The diaphragm can be replaced without removing the valve body

Step 1

Only use Alfa Laval diaphragms

Step 2

Actuate the valve to the “open” position for:

- normally closed and air/air actuators, apply air pressure of the lower actuator port
 - normally open actuators, relieve the air pressure of the upper actuator port
-

Step 3

Remove the body fasteners using a cross-wise sequence

Step 4

Actuate the valve in the “closed” position for:

- normally closed actuators, apply air pressure to the lower actuator port
 - normally closed and air/air actuator, apply air pressure to the upper actuator port
-

Step 5

Remove the diaphragm from the actuator

Button-style compressor:

- Remove diaphragm by pulling it out slightly. (See Fig. 1)

Threaded-style compressor:

- Unthread the diaphragm in a counter-clockwise direction. (See Fig. 2)

Bayonet-style compressor:

- Rotate the diaphragm 90° and remove. (See Fig. 3)

NOTE!: see fig. 1-3, reverse action of step 9.

Step 6

Check and clean threads and bayonets of the compressor

Study the instructions carefully and pay special attention to the warnings!
Ensure that the valve operates smoothly.
The items refer to the parts list and service kits section.

Step 7

Make sure that the new diaphragm and the contact area on the valve body are clean and dry

Step 8

Make sure the actuator compressor matches the connection on the diaphragm. Should this not be the case, replace the compressor

Step 9

With the actuators in “closed” position, install diaphragm as follows:

- For button-style compressors, insert the diaphragm with a push and slight rotation. Rotate the diaphragm until screw holes match (fig 1).
- For threaded-style compressors, thread the diaphragm into the compressor in a clockwise direction (fig. 2). Do **not** overtighten! Then, if necessary, turn the diaphragm in a counter-clockwise direction until the screw holes match.
- Bayonet-style compressor insert diaphragm with bayonet into the deepening of the compressor. Rotate diaphragm 90° (fig. 3). Screw holes must match.

Fig.1




Fig.2





Fig.3



Do **not** overtighten!

Step 10

Actuate the valve to the “open” position - see step 2

Step 11

Align the to the valve body using fasteners. Assemble the nuts and, if necessary, use washers. To secure the actuator and body, tighten the fasteners by hand.

Step 12

Actuate the valve to the “closed” position, so that the diaphragm can properly fit to the weir - see step 4. Tighten the body fasteners cross-wise using a wrench.

5 Maintenance


Study the instructions carefully and pay special attention to the warnings!
 Ensure that the valve operates smoothly.
 The items refer to the parts list and service kits section.

Step 13

Actuate the valve to the “open” position - see step 2. Slightly re-tighten the body fasteners cross-wise with a wrench.

Note: Proper assembly extends the life of the diaphragm. Correctly assembled diaphragms have a Crescent-shaped bulge in the diaphragm edge which can be observed from the side (fig. 4).

Fig 4



Step 14

Test the valve for proper function

NOTE!: Check the fasteners 24 hours after operation of the valves. In case of leakage at the body, depressurise the system and, if necessary, tighten the fasteners again as described. If leakage continues, replace the diaphragm.

5.3 Fasteners for assembly - Full composite actuator


Pos. 9 4 cylindrical hexagon fasteners DIN 912 ST-A2
 Pos 14 Body forged

DN	Inch	Rubber	PTFE
15	1/2	M 6 x 25	M 6 x 25
20	3/4	M 6 x 20	M 6 x 25
25	1	M 8 x 25	M 8 x 25
40	1 1/2	M 10 x 30	M 10 x 30
50	2"	M 10 x 35	M 10 x 35

Pos. 14 Body cast

DN	Inch	Rubber	PTFE
15	1/2	M 6 x 20	M 6 x 20
20	3/4	M 6 x 20	M 6 x 25
25	1	M 8 x 25	M 8 x 30
32	1 1/4	M 8 x 25	M 8 x 30
40	1 1/2	M 10 x 35	M 10 x 35
50	2"	M 10 x 35	M 10 x 40

Note: Tighten the 4 fasteners cross-wise



Study the instructions carefully and pay special attention to the warnings!
 Ensure that the valve operates smoothly.
 The items refer to the parts list and service kits section.

5.4 Fasteners for assembly - Actuator with intermediate part in stainless steel


- Pos. 9 4 cylindrical hexagon fasteners DIN 912 ST-A2
 Pos. 13 4 nuts + washer DIN 934 ST A4 / DIN 125 ST A-2
 Pos. 14 Body forged

DN	Inch	Rubber	PTFE
8	¼	M 4 x 20	M 4 x 20
15	½	M 6 x 30	M 6 x 30
20	¾	M 6 x 30	M 6 x 30
25	1	M 8 x 30	M 8 x 35
40	1 ½	M 10 x 35	M 10 x 40
50	2"	M 10 x 40	M 10 x 45

- Pos. 14 Body cast

DN	Inch	Rubber	PTFE
8	¼	M 4 x 20	M 4 x 20
15	½	M 6 x 30	M 6 x 30
20	¾	M 6 x 30	M 6 x 30
25	1	M 8 x 30	M 8 x 35
40	1 ½	M 10 x 35	M 10 x 40
50	2"	M 10 x 40	M 10 x 45

Note: Tighten the 4 fasteners cross-wise



5.5 Replacement of actuator seals

Mode NC and 1) this step not possible for size DN8 (¼")

- Unscrew the indicator cap (1) and turn over the complete actuator
- Actuate the valve to the "open" position - see section 6.2
- Remove the fasteners, nuts and washers (9 / 13) on the valve body (14)
- Remove diaphragm (8) – see section 6.2
- Remove compressor including diaphragm holder (12)
- Remove snapper with screwdriver (type C/SS and C/C)
- Remove lock screw with screwdriver (type SS/SS)
- Remove the intermediate part (10) from the upper housing (3) by turning counter-clockwise
- Pull piston (7) out of upper housing (3)
- Replace piston sealing (11) and other seals (11) (lubricate!)

Attention: please use FDA certified lubrication – Alfa Laval recommends Klüber Lubrication Paraliq GTE 703.
 Mounting is done in the reverse order

NO mode



Replacement of actuator seals for NO mode should only be carried out by Alfa Laval.




NOTE:

For application in ex-proof areas, you must only wipe the composite actuator only with a moist cloth!

5 Maintenance

Study the instructions carefully and pay special attention to the warnings!
 Ensure that the valve operates smoothly.
 The items refer to the parts list and service kits section.




*It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.*

6.1 Control diagram / modes


a) **Function NC: normally closed** with a solenoid valve 3/2 way for connection below

Fig. a




b) **Function NO: normally open** with a solenoid valve 3/2 way for connection above

Fig. b



c) **Function AA: air/air** with a solenoid valve 4/2 and 5/2 way for connection below and above

Fig. c



6 Technical data

It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.

6.2 Maximum working pressures

Version complete composite (C/C)

Table 1. Actuator NC
Max. working pressure at 23° C (73° F) medium temperature

Size		EPDM					PTFE				
DN	Inch	Gr.	→	↔	↔	Gr.	→	↔	↔	psi	
			bar	psi	bar		psi	bar	psi		bar
15	(½")	1	10	145	10/9	145/130.5	2	10	145	10/9	145/130.5
20	(¾")	2	10	145	10/9	145/130.5	2	10	145	10/9	145/130.5
25	(1")	2	10	145	9/8	130.5/116	3	10	145	10/9	145/130.5
40	(1½")	4	10	145	10/9	145/130.5	5	10	145	10/9	145/130.5
50	(2")	4	10	145	8/7	116/101.5	5	10	145	10/9	145/130.5

Table 2. Actuator NO, AA
Max. working pressure at 23° C (73° F) medium temperature

Size		EPDM					PTFE				
DN	Inch	Gr.	→	↔	↔	Gr.	→	↔	↔	psi	
			bar	psi	bar		psi	bar	psi		bar
15	(½")	1	10	145	10/9	145/130.5	2	10	145	10/9	145/130.5
20	(¾")	2	10	145	10/9	145/130.5	2	10	145	10/9	145/130.5
25	(1")	2 *1	10	145	10/9	145/130.5	3	10	145	9/8	130.5/116
40	(1½")	4 *2	10	145	10/9	145/130.5	4 *2	10	145	10/9	145/130.5
50	(2")	4 *2	10	145	10/9	145/130.5	5	10	145	10/9	145/130.5

- Working pressure on one side
- ↔ Working pressure on both sides

NO/AA measuring with 5 bar (72.5 psi) control pressure

*1 = stainless steel intermediate part Gr3

*2 = stainless steel intermediate part Gr5

6 Technical data

It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.

Version composite with stainless steel intermediate part (C/SS)

Table 3. Actuator NC
Max. working pressure at 23° C (73° F) medium temperature

Size		Gr.	EPDM				Gr.	PTFE			
DN	Inch		→		↔			→		↔	
			bar	psi	bar	psi		bar	psi	bar	psi
8	(¼")	1	10	145	10/9	145/130.5	1	10	145	10/9	145/130.5
15	(½")	1	10	145	10/9	145/130.5	1	Not available for PTFE			
15	(½")	2	10	145	10/9	145/130.5	2	10	145	10/9	145/130.5
20	(¾")	2	10	145	10/9	145/130.5	2	10	145	10/9	145/130.5
25	(1")	2	10	145	10/9	145/130.5	2	10	145	10/9	145/130.5
40	(1½")	5	10	145	10/9	145/130.5	5	10	145	10/9	145/130.5
50	(2")	5	10	145	10/9	145/130.5	5	10	145	10/9	145/130.5

Table 4. Actuator NO, AA
Max. working pressure at 23° C (73° F) medium temperature

Size		Gr.	EPDM				Gr.	PTFE			
DN	Inch		→		↔			→		↔	
			bar	psi	bar	psi		bar	psi	bar	psi
8	(¼")	1	10	145	10/9	145/130.5	1	10	145	10/9	145/130.5
15	(½")	1	10	145	10/9	145/130.5	2	10	145	10/9	145/130.5
20	(¾")	2	10	145	10/9	145/130.5	2	10	145	10/9	145/130.5
25	(1")	2 *1	10	145	10/9	145/130.5	3	10	145	9/8	130.5/116
40	(1½")	4 *2	10	145	10/9	145/130.5	4 *2	10	145	10/9	145/130.5
50	(2")	4 *2	10	145	10/9	145/130.5	5	10	145	10/9	145/130.5

→ Working pressure on one side
↔ Working pressure on both sides

NO/AA measuring with 5 bar (72.5 psi) control pressure

*1 = stainless steel intermediate part Gr3

*2 = stainless steel intermediate part Gr5

6 Technical data

It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.

Version complete stainless steel (SS/SS)

Table 5. Actuator NC

Max. working pressure at 23° C (73° F) medium temperature

Size		Gr.	EPDM				Gr.	PTFE			
DN	Inch		→		↔			→		↔	
			bar	psi	bar	psi	bar	psi	bar	psi	
8	(1/4")	1	10	145	10/9	145/130.5	1	10	145	10/9	145/130.5
15	(1/2")	2	10	145	10/9	145/130.5	2	10	145	10/9	145/130.5
20	(3/4")	3	10	145	10/9	145/130.5	3	10	145	10/9	145/130.5
25	(1")	3	10	145	10/9	145/130.5	3	10	145	10/9	145/130.5
40	(1 1/2")	5	10	145	10/9	145/130.5	5	10	145	10/9	145/130.5
50	(2")	5	10	145	10/9	145/130.5	5	10	145	10/9	145/130.5

Table 6. Actuator NO/AA

Max. working pressure at 23° C (73° F) medium temperature

Size		Gr.	EPDM				Gr.	PTFE			
DN	Inch		→		↔			→		↔	
			bar	psi	bar	psi	bar	psi	bar	psi	
8	(1/4")	1	10	145	10/9	145/130.5	1	10	145	10/9	145/130.5
15	(1/2")	2	10	145	10/9	145/130.5	2	10	145	10/9	145/130.5
20	(3/4")	3	10	145	10/9	145/130.5	3	10	145	10/9	145/130.5
25	(1")	3	10	145	10/9	145/130.5	3	10	145	10/9	145/130.5
40	(1 1/2")	5	10	145	10/9	145/130.5	5	10	145	10/9	145/130.5
50	(2")	5	10	145	10/9	145/130.5	5	10	145	10/9	145/130.5

→ Working pressure on one side
↔ Working pressure on both sides

NO/AA measuring with 5 bar (72.5 psi) control pressure

*1 = stainless steel intermediate part Gr3


*2 = stainless steel intermediate part Gr5

Connection for control medium

DN	Inch	C/SS C/C	SS/SS
8	1/4"	G1/8"	M5
15	1/2"	G1/8"	M5
20	3/4"	G1/8"	M5
25	1"	G1/8"	M5
40	1 1/2"	G1/4"	G1/8"
50	2"	G1/4"	G1/8"

It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.


6.3 Size



Type	C/SS C/C	SS/SS
1	68	60
2	96	92
3	120	115
4	150	
5	180	166

6.4 Maximum working temperatures

Temperatures for actuator



6 Technical data

It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.

6.5 Control pressure (guidelines)

- Maximum allowable control pressure: 6 bar (87 psi) for mode NC
- Lower control pressure possible by reducing the spring sets
- Control medium: compressed air (oil-free) inert, non-aggressive gases
- Maximum temperatures of control medium 40° C (104° F)

6.6 Control pressure diagram


Description:

PN operating nominal pressure in bar P control pressure in bar


Actuator: Complete Composite (C/C) DN15-DN50 (½" to 2") and Complete Stainless Steel (SS/SS) DN15-DN50 (½" to 2")

Diaphragms: Elastomers/PTFE


NC - EPDM-Membrane



NC - PTFE-Membrane




Working Pressure (bar)



Working Pressure

Working Pressure (bar)




Working Pressure

6 Technical data


It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.

Actuator: Composite with Stainless Steel intermediate part (C/SS) DN8-DN50 (1/4" - 2")
Diaphragms: Elastomers/PTFE


NC - EPDM-Membrane




NC - PTFE-Membrane



Working Pressure (bar)



Working Pressure (bar)



Working Pressure


Working Pressure

6 Technical data


It is important to observe the technical data during installation, operation and maintenance.
Inform the personnel about the technical data.

Actuator: Complete Composite (C/C) DN15-DN50 (½" to 2")
Diaphragms: Elastomers/PTFE


NO/AA - EPDM




NO/AA - PTFE



Working Pressure (bar)



Working Pressure (bar)




Working Pressure


Working Pressure

Actuator: Composite with stainless steel intermediate part (C/SS) DN8-DN50 (¼" - 2")
Diaphragms: Elastomers/PTFE

NO/AA - EPDM





NO/AA - PTFE



Working Pressure (bar)

Working Pressure (bar)



Working Pressure

Working Pressure

How to contact Alfa Laval

Contact details for all countries are continually updated on our website.

Please visit www.alfalaval.com to access the information directly.

© Alfa Laval Corporate AB

This document and its contents is owned by Alfa Laval Corporate AB and protected by laws governing intellectual property and thereto related rights. It is the responsibility of the user of this document to comply with all applicable intellectual property laws. Without limiting any rights related to this document, no part of this document may be copied, reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the expressed permission of Alfa Laval Corporate AB. Alfa Laval Corporate AB will enforce its rights related to this document to the fullest extent of the law, including the seeking of criminal prosecution.